



door or window alarm

instruction sheet

Please keep these instructions in a safe place for future reference

Contents:


- 2 sets of window/door alarms (batteries installed)
- 3 x LR44 batteries (installed) for each piece

The window/door alarm is especially designed for to provide extra security and peace of mind by sounding an alarm when an intruder tries to open a window or door.

There is no assembly required.

Installation: No tools are required.

- When you are ready to install, place each piece of 1 set on the window or door you wish to secure.
- Double check that the 2 pieces will not be more than 1/2" apart.
- Remove the backing on the adhesive strip on the back of the Magnetic Contact and firmly press into place on the door or window.
- Pull the plastic tab between the battery compartment and battery to activate the battery.
- Remove the backing on the Main Unit, line up the 2 arrows (see below) and press firmly into place on the window or door frame.



Operation:

- When the 2 arrows are lined up and the units are securely in place, remove the Disarm Key by pulling up on the Key.
- When the window or door is opened or the Disarm Key is removed, it will sound a loud alarm.
- Keep the Disarm Key close by to use when you want to disarm the unit or after the alarm has been tripped.

Alarm volume: 89 dB(A) measured at a distance of 3 feet.

Battery Replacement:

- Open the battery compartment cover (shown above) by sliding the cover down.
- Remove the 3 old batteries and replace with 3 new LR44 button cell alkaline batteries following the polarity diagram.
- Replace the battery compartment cover.

Caution:

- **Batteries may leak harmful liquids or ignitable materials or explode causing injury and product damage.**
- Do not mix old and new batteries or other battery types
- Replace all batteries of the same kind at the same time
- Replace fully discharged batteries immediately

Note:

This product is designed to be a deterrent. It is an alarm signal. It does not guarantee protection.

